AUTOSPY VIEWER

AutoSPY Viewer is a free, standalone viewer software for watching, marking and measuring AutoSPY trace documents. It allows users of Analyser AutoSPY to

- ✔ present their recorded signal data to all, who do not have a license of Analyser AutoSPY (such as other divisions or companies), and
- ✔ use their own license of Analyser AutoSPY for recording signals at the shop floor, while performing first simple analyses of previously logged signal data in the office at the same time.

Range of Functions

The AutoSPY Viewer is **free** and, hence, has a limited range of functions compared to the Analyser AutoSPY. Nevertheless the Viewer enables you

- ✔ to watch signal traces of any desired length without limitations in signal count,
- ✔ to configure signal properties like naming, coloring, or scaling,
- ✔ to arrange signals in a stack (one upon the other) in graph view for easy comparison,
- ✔ to quickly measure time spans, frequencies, amplitudes and sample rates via cursors, and
- ✔ to mark and describe important events in the trace by placing flags and time dimensioning.

The Viewer **lacks** following functions of Analyser AutoSPY:

- recording new signal data
- importing, exporting, and printing signal data
- script-based analysis and searching in signal data

Installation and Redistribution

AutoSPY Viewer is available in English and German and consists of only one executable file per language. If you have installed the Analyser AutoSPY completely, you will find these files in the installation directory of AutoSPY:

- **AutoSPYViewerDeu.exe** for the Viewer in German language
- **AutoSPYViewerEng.exe** for the Viewer in English language

To download the AutoSPY Viewer separately from our website, please use the following link:
https://www.autospy.de/download/AutoSPY_Viewer.zip

You may redistribute the AutoSPY Viewer without any limitations. Registration or notification is not required. In case of redistribution you only have to pick and send the executable in the desired language to the recipient. The Viewer has not to be installed and does not require administrator privileges or any program files of Analyser AutoSPY to run.